

70cm Gas on Glass COOKTOP

PRODUCT CODE: **ECT750GBK2**



FEATURES:

- + 5 gas burners includes left side wok burner
- + Front control knobs (chrome or black finish included)
- + Automatic ignition
- + Non-slip cast iron trivets
- + Wok support trivet included
- + Easy clean surface
- + Flame failure safety device
- + Natural gas or LPG (jets included)
- + Modern design glass cooktop

KEY FEATURES:

GAS ON GLASS

The best of both worlds. The efficiency of gas, combined with the easy clean glass cooktop, the non-porous glass ensures the unit is simple and easy to operate.

FLAME FAILURE SAFETY DEVICE

The flame failure device is a safety mechanism which ensures the gas is automatically turned off in the case of the flame extinguishing.

AUTOMATIC IGNITION

The gas cooktop uses a one-touch electronic ignition system. Simply push the knob down and turn to the desired setting, the flame will then ignite automatically.

SPECIFICATIONS:

Electrical Requirements	Cooktop is supplied with a 10 amp plug and cord
Voltage	220V-240V
Frequency	50/60Hz
Cooking Zones:	
- Wok burner	12.96 MJ/h
- 1 Rapid burner	10.8 MJ/h
- 2 Semi burner	6.30 MJ/h each
- 1 auxiliary burner	3.6 MJ/h
Weight	15.5kg (Gross)/ 13.3kg (Net)
Product Dimensions	W750mm x H90mm x D510mm
Barcode	9347726035901



cooking range

3
YEARS

Warranty

SAFETY INFORMATION

- The heating and cooking surfaces of the appliances become hot when in use, take all due precautions.
- Unstable pans should not be used on the appliances as they can cause an accident by tipping or spillage.
- Never leave the appliance unattended when cooking.
- Please refer to the manual for more information

CLEANING AND MAINTENANCE

- Cleaning operations must only be carried out when the appliance is completely cool.
- Clean the appliance regularly, preferably after each use
- Abrasive cleaners or sharp object will damage the appliance surface; you should clean it using water and a little washing up liquid

INSTALLATION DIAGRAM

