
Sigma ROUND BUTTON FLUSH PLATE


FOR SIGMA CISTERN

Features

- For use with Sigma cisterns
- Dual flush
- Made from ABS







Available in



Chrome SIG41-C

Brushed Nickel

SIG41-BN



Matte Chrome SIG41-MC

Gun Metal

SIG41-GM



Brushed Copper

SIG41-CO

Matte White SIG41-MW



Matte Black
SIG41-MB



Urban Brass SIG41-UB

Cleaning & Care

- Regularly clean with mild soapy water using a microfibre cloth.
- In highly polluted or coastal locations, we recommend cleaning 2-3 times per week.
- Do not use harsh detergents, bleach, cream cleaners or citrus based cleaners. These substances are abrasive and will damage the surface.
- Do not use undue pressure and wipe in one direction only.

We aim to ensure that specifications are correct at the time of publication. All measurements are shown in millimetres. Always use measurements of actual product received for final specification as the technical drawing may contain differences. Due to printing limitations, physical colour may vary from the image shown. Fienza reserves the right to make modifications without prior notice.