60cm Freestanding 14 Place

DISHWASHER

PRODUCT CODE: **ED614SX**



FEATURES:

- 14 place setting
- Stainless Steel finish
- Half load option
- Delayed start function
- Extra dry function
- Height adjustable top basket
- Child Lock Safety
- Concealed Heating Element
- Removable top cover
- Start/pause option

- 6 Wash programs
 - + Intensive
 - + Eco
 - + 90 minute
 - + Rapid
 - + Heavy
 - + Glass
- 3 star energy rating
- 4.5 star water rating

PRODUCT DIMENSIONS

euro cooking

598mm wide x 600mm depth x 845mm height (adjustable feet 20mm)

KEY FUNCTIONS

14 PLACE SETTINGS

With 14-place settings the ED614SX provides results with greater flexibility allowing you the flexibility to select the correct setting for your dishwashing requirements.

2 LEVEL HEIGHT ADJUSTMENT TOP BASKET

The adjustable top basket can be set higher or lower in the washing baskets, ensuring wash space for those larger cooking utensils and dishes.

SIMPLE ELECTRONIC PROGRAM CONTROLLER

This ED614SX dishwasher operates via an electronic push button control. You can select your preferred program by using the electronic push buttons on the top right of the front panel.

6 WASH PROGRAMS

The ED614SX dishwasher provides you with the choice of 6 different wash programs to ensure you can select the type of wash which best suits whether it be those few dirty dishes or after that large dinner party.

INSTALLATION INFORMATION

Please refer qualified installer to our product instruction

FILTER CLEANING INFORMATION

Drain pump filter: requires cleaning monthly. This will ensure no interruptions with the dishwasher operation.

SPECIFICATIONS:

Water Consumption	12.5 Litres per wash (using eco program) (4.5 star water rating
Energy Usage	295 kwh per year (Cold water connection, using ECO program seven times per week) (3 star energy rating)
Noise Level	49db
Inlet Hose/Drain Hose Length:	1.8m / 1.4m
Water Connection	Cold water (as dishwasher has its own heating element)
Weight	54.5kg (Gross) / 48.0kg(Net)



