


Opal Twin Shower set





SPECIFICATION

OVERHAND SHOWER WELS RATING 3STAR 9L/Min

HAND SHOWER WELS RATING 3STAR 9L/Min

WATERMARK LICENSE WM-060093

TEMPERATURE RATING Min 1°C-Max 75°C

PERSSURE RATING Min 150KPa-Max 500Kpa

AVAILABLE FINISH



GRAPHITE

BRUSHED NICKEL

NR251905eBN



BRUSHED BRONZE NR251905eBZ

NR251905eGR



BRUSHED GOLD

NR251905eBG

MAINTENANCE AND CARE

All surfaces should be cleaned with mild liquid detergent or soap and water. Do not use cream cleaners or citrus based cleaning products, as they are abrasive. Use of unsuitable cleaning agents may damage the surface. Any damage caused in this way will not be covered by warranty

PACKING INCLUDES

- -1x hand shower (built-in check valve)
- -1x shower head
- -1x shower arm
- -1x shower rail
- -1x1.5m PVC hose
- -2x back plates
- -1x slider bracket










Important

All products must be installed by licensed plumbers.

All pipework must be thoroughly flushed prior to installation, as foreign materials may block the flow regulating device and reduce the flow of water.




1.Drill a ϕ 6mm hole at the downwards outlet vertical downward position in the recommended range.





2. Screw the adapter onto the outlet. Push wall plug into drilled hole. Fit lower mounting pillar in place with screw. Tighten firmly.




Screw shower rail into shower arm component. Tighten firmly.


Push 2 back plates onto shower arm component and lower mounting pillar.



4. Locate and push shower rail assembly onto wall adaptors. Tighten grub screws firmly with allen key provided.
Slide the back plates against the wall/tile face properly.



5.Screw shower head to shower arm with care. (Note the rubber washer in the shower head.)



6. Please noted the rubber washer in the hand shower.

Connect shower rail and hand shower with hose. TEST & CHECK FOR LEAKS.