

# 90cm Ceran Touch Electric COOKTOP

PRODUCT CODE: **ECT900C62**



## FEATURES:

- + Smooth Ceran glass electric cooktop
- + Cooktop with double radiant & oval radiant coil
- + 6 hi-lite elements
- + Front sensor touch control operation
- + Overheating detection
- + Auto switch off safety
- + Residual heat indicator
- + 99 minute timer function
- + 9 power stage settings
- + Child lock

## KEY FEATURES:

### RESIDUAL HEAT INDICATOR

To ensure that you know which electric hotplate is in use, this cooktop is equipped with a heating level indicator. After cooking, there will be some residual heat remaining & the letter "H" will appear to warn you to keep away from burner until it cools down.

### CHILD SAFETY LOCK

The child safety lock acts as protection to ensure that your desired temperature cannot be altered without

### SENSOR TOUCH CONTROL

The ECT900C62 cooktop is equipped with a stylish touch sensor control panel, adding a touch of style and elegance to your kitchen.

### 6 HILITE ELEMENTS

This cooktop is fitted with 6 hi-lite elements to ensure rapid heat up.

### SMOOTH CERAN GLASS COOKTOP

A high-grade Ceran glass is used for this cooktop to ensure easy cleaning of the smooth Ceran surface.

## SPECIFICATIONS:

<b>Electrical Requirements</b>	40 amp dedicated circuit from cooktop to main switchboard
<b>Voltage</b>	220V-240V
<b>Frequency</b>	50Hz/60Hz
<b>Total Rated Load:</b>	6500W - 7800W
<b>Cooking Zones:</b>	
- Front Left Element	1000W/2200W
- Rear Left Element	1100W/ 2600W
- Rear Right Element	1800W
- Front Right Element	1200W
<b>Weight</b>	13.5kg (Gross)/ 11.5kg (Net)
<b>Product Dimensions</b>	W900mm x D520mm x H55mm
<b>Barcode</b>	9347726035697

  
cooking range

**3**  
YEARS  
Warranty

## SAFETY INFORMATION

- The heating and cooking surfaces of the appliances become hot when in use, take all due precautions.
- Unstable pans should not be used on the appliances as they can cause an accident by tipping or spillage.
- Never leave the appliance unattended when cooking.
- Please refer to the manual for more information

## CLEANING AND MAINTENANCE

- Cleaning operations must only be carried out when the appliance is completely cool.
- Clean the appliance regularly, preferably after each use
- Abrasive cleaners or sharp object will damage the appliance surface; you should clean it using water and a little washing up liquid

## INSTALLATION DIAGRAM

